

SIMPLE AND CONVENIENT SETTINGS

For exceptional comfort, all of the settings are hydraulically controlled from the tractor cab. You are able to intervene at any time, to change the working depth of your opening discs **2** for cut and mix optimization. The same is true of your levelling discs **3**, for perfect levelling. The tines are fixed to the frame, so their depth is regulated by the machine as a whole. The drawbar cylinder **1** and roller cylinders **5** adjust tine depth for a perfectly positioned machine at work. The hydraulic functions are centralized on a KTH 105 4 hydraulic selector **4**. This machine only requires 2 double acting valves.



EVEN MORE POSSIBILITIES

Choice of simple or ball joint linkage for perfect adaptation to your different tractors.

Plant cover seeder. Optimising your ploughing, sowing cover crops at the same time. With a seed hopper capacity of 200, 380 or 600 litres, this seeder allows you to work autonomously on jobs big or small. You can also sow canola seeds in a single pass.



Less than 3 m transport width.

